+ AUTODOC CLUB


How to change front antiroll bar links on MERCEDES-BENZ VITO / MIXTO Box (W639) – replacement guide







SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

MERCEDES-BENZ VITO / MIXTO Box (W639) 110 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 113 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 116 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 122 CDI 3.0, MERCEDES-BENZ VITO / MIXTO Box (W639) 115 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 111 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 122 3.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 109 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 109 CDI 2.2, MERCEDES-BENZ VITO / MIXTO Box (W639) 111 CDI 2.2 4x4, MERCEDES-BENZ VITO / MIXTO Box (W639) 115 CDI 2.2 4x4, MERCEDES-BENZ VITO / MIXTO Box (W639) 126 3.5, MERCEDES-BENZ VITO / MIXTO Box (W639) 123 3.7 (639.603)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ VITO Bus (W639) 115 CDI 2.2


CLUB.AUTODOC.CO.UK 1–9







REPLACEMENT: ANTI ROLL BAR LINKS – MERCEDES-BENZ VITO / MIXTO BOX (W639). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18

- Torx bit T40
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2–9







AUTODOC recommends:

- Replace the stabiliser links on MERCEDES-BENZ VITO / MIXTO Box (W639) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR LINKS – MERCEDES-BENZ VITO / MIXTO BOX (W639). RECOMMENDED SEQUENCE OF STEPS:

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3–9







4 Unscrew the wheel bolts.



AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. MERCEDES-BENZ VITO / MIXTO Box (W639)
- Remove the wheel.



- 6 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #18. Use Torx T40. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4–9







Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #18. Use Torx T40. Use a ratchet wrench.



9 Remove the stabilizer rod.



Replacement: anti roll bar links – MERCEDES-BENZ VITO / MIXTO Box (W639). Tip from AUTODOC:

• Examine stabiliser bushes. Replace them if needed.

10 Install a new rod, tighten the fasteners.



CLUB.AUTODOC.CO.UK 5–9







Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #18. Use Torx T40. Use a torque wrench. Tighten it to 85 Nm torque.



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #18. Use Torx T40. Use a torque wrench. Tighten it to 85 Nm torque.



- Treat all joints of the stabiliser link. Use copper grease.
- Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 6–9







AUTODOC recommends:

Replacement: anti roll bar links – MERCEDES-BENZ VITO / MIXTO Box (W639).
After applying the spray, wait a few minutes.

16

Install the wheel.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. MERCEDES-BENZ VITO / MIXTO Box (W639)
- Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 130 Nm torque.



CLUB.AUTODOC.CO.UK 7–9







19

Remove the jacks and chocks.








CLUB.AUTODOC.CO.UK 8-9





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

ANTI ROLL BAR LINKS: A WIDE SELECTION

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 9–9